



R		13, 14, 4,	2,	3,		5,		7,	6,	9,	15, 10,	11,	12,	14,
C	1, 4, 3,	2,	5, 6, 7, 10,	8, 28,		31, 30, 13, 20,	11,	29,	19, 15, 16, 18,	12,	17,	14,	9,	22,
L	1,	2, 4, 6, 20, 21, 22, 23, 24	3, 5, 7,			25,	8, 10, 12, 9, 11, 13,	14,	15,		16, 17,		20, 21, 22, 23, 24, 26,	18, 19,



PATICE ELEKTRONEK



ROZSAHY	SEPNUTÉ SPÍNAČE
KV	P1, P3, P5, P8,
SV	P2, P4, P6, P9,
AV	P7, P10,